


Hardware Set Up

Click on Store & Station Set Up, then click on Other Hardware:



The screenshot shows a software window titled "Store & Station Configuration Set Up" with a tabbed interface. The "Other Hardware" tab is selected. Under the "Cash Drawer" sub-tab, there are several configuration rows:

Field	Value	Action
Cash Drawer IP	[Empty Text Box]	Save
Cash Drawer Port	[Dropdown Menu]	Save
Show Cash Drawer Buttons on Screen?	Yes	Save
Open Cash Drawer when complete order?	No	Save
Open Cash Drawer for all types of Payments?	No	Save
Open cash drawer when pay at order status?	No	Save
Password Open cash drawer when pay at order status?	[Dropdown Menu]	Save

At the bottom of the window, there is a search bar labeled "Enter Key Words:" with "Search" and "Close" buttons.

- Cashdrawer IP: This is the IP address of the computer that the cashdrawer is attached to
- Cashdrawer Port: This is the port number on which the cashdrawer is attached to the computer.
- For native drivers, use the port name such as COM1, etc.
- For ESC/POS mode, use EPSON COM1 etc.
- For Windows Drivers, use "Windows <printer name>"

- Pole Display Port: This is the port number on which the Pole Display is attached to the computer. It is normally a serial port such as COM1, etc.
- Caller ID Port: This is the port number on which the Caller ID Modem is attached to the computer. It is normally a serial port such as COM1, etc.

Caller ID by default is not enabled. To enable it, select Enable Caller ID to Yes. You can show all caller IDs to all computers, or specify line 1 to one computer, line 2 to another computer, and so on so forth.